

Product Type Keyboards

Product Item All

Symptom Keyboards are conflicting due to incompatibility

Solution

- 1) Disconnect the power from your keyboard
- 2) Reconnect the power
- 3) Within 5 seconds press the keys below simultaneously

- 4) The LCD display should change to: Special Config
- 5) Within 5 seconds press the reverse play key
- 6) The LCD display should change to Change KBD Id
- 7) Within 5 seconds enter the new Id number (1-9) and press the 'Enter' key.
- 8) The LCD display should change to

Change KBD ID

New SELFUNT = 00n

(Where n is the new number)

Author Simon Hooton Date 17/11/05